

5100, 5400 & 5800 SERIES

- CUT PARTS FROM SPRUES (DO NOT BREAK OFF)
- IF NECESSARY, LIGHTLY SAND EDGES OF PLUG DOORS UNTIL THEY FIT FLUSH

