



ACCURAIL®
MADE IN THE USA

5600 SERIES EXTERIOR POST STEEL BOX CAR

TOOLS NEEDED: Small Phillips Screwdriver, Sharp Hobby Knife or Side Cutters, Needle Nose Pliers

- Cut detail parts from sprues with side cutters or a sharp hobby knife.
- Use Plastic Cement or CA (Super Glue or Super Glue Gel) for small parts.
- Assemble underframe before cementing it into car body.

- 1 Trim all knockout pins from sides of underframe.
- 2 Cement Air Reservoir, Triple Valve and AB Valve into underframe.
- 3 Install trip pins into couplers with needle nose pliers, then install couplers into coupler pockets. Screw coupler covers into place but do not overtighten.
- 4 Install wheels into trucks, then install trucks into underframe. Do not over-tighten screws.
- 5 Clean car weight with silicone adhesive, plastic cement or double-sided tape before attaching to underframe. Install Underframe into car body. Cement if desired.

If a plug door with lettering is supplied, it should be used.

Otherwise use Youngstown Door.
Glue Doors in place with plastic cement or Super Glue Gel.

